



Bluetooth headset

IG1846/47

User's manual


Thank you for purchasing the iGear.com.au Bluetooth Headset.

Before using the product, please read the manual carefully to learn more about the functions and operation of the device.

Do not modify or repair the iGear.com.au Bluetooth Headset. Doing so may result in user's injury, complete breakdown of the device or losing warranty.

We hope that you will enjoy the iGear.com.au Bluetooth Headset.

Appearance



Specification

The Bluetooth Headset is compatible with the Bluetooth specification v3.0, v1.1 & v1.5. If you have a device with other standards, you have to check the compatibility with the product website. Before you start using the Bluetooth Headset, you will have to charge the battery and pair the headset with a compatible device with Bluetooth technology.

NB: Do not put memory cards or other magnetic objects near the headset. The device has an internal, non-removable, rechargeable battery. To avoid damage, do not attempt to remove the battery from the device.

Charging

1. Connect the charger cable to the headset and socket.
2. The red indicator light will illuminate when charging commences. If charging does not start, disconnect the charger from the socket and try to connect again. Charging can take up to 2 hours.
3. When the battery is fully charged, the indicator light will turn blue.
4. Disconnect the charger from the cable and socket.

ON

Press and hold the Multifunction button. When the headset is connected with a paired device, you will hear a sound. After pairing devices, the indicator light will turn blue.

Pairing

1. Switch on your phone and the Bluetooth headset.
2. Activate the Bluetooth module on the phone and search for Bluetooth devices and select the headset, labelled 'BT-IGEAR' from the list of found devices.
3. Enter passcode: 0000
4. When the pairing process is successful, you will hear a sound.

To disconnect the headset from the phone, do the following:

- Press the Multifunction button,
- Disconnect the headset in the Bluetooth menu in your phone.
- Move the headset more than 10m away from your mobile.

You don't need to delete the pairing with the headset to disconnect.

Troubleshooting

If you can not connect the headset to your mobile, try the following:

- ensure that the headset is charged, switched on and paired with your phone.
- Ensure the Bluetooth module on your phone is activated
- Check if the headset is less than 10m from your mobile and there are no obstructions between the headset and the phone.
- Reset the headset by turning it off and then on again.
- Connect the headset to the charger and press the Multifunction Button and the middle of the Volume Key.



Head Office : 07 3354 2458

PO Box 430 Alderly QLD 4051 Australia
sales@igear.com.au | www.igear.com.au