

展开尺寸: 140 x 100mm
折好尺寸: 70 x 100mm
工艺: 105g双铜纸四色双面印刷
对折

Unfolded size: 140 x 100mm
Folded size: 70 x 100mm
Process: 105g double copper paper four-color double sided printing folded in half

IG1942



Portable Power Bank

USER MANUAL

This product is applicable to digital products 5V input. Please read the whole user manual prior to use.

OPERATING INSTRUCTIONS

Power Button: This button is used to turn on/off the power bank, check battery status, and turn on/off the flashlight.

- 1 Press the power button once to check battery percentage and turn on the power-bank.
- 2 Double press the power button to turn off the power-bank.
- 3 Long press the power button to turn on the flashlight.

CHARGING THE POWER-BANK

- 1 Connect the power-bank to a computer, laptop or 240V power adaptor using a Type-C cable (not included) inserted into Type-C input port.
- 2 Once Type-C cable and power is connected the digital power indicator will flash, once fully charged the indicator will stop flashing and show 100%.

BATTERY INDICATOR

The battery indicator will show battery percentage when power button is pressed.

USING THE POWER-BANK

- 1 Select the relevant cable for your device from one of the four power cable options. iPhone, Micro USB, Type-C USB or use an existing cable via the USB power cable.
- 2 Turn on the power-bank and your device will commence charging.

IMPORTANT NOTES:

- 1 Ensure your power-bank is fully charged before first use.
- 2 To avoid possible damage, do not use any faulty or damaged cables to charge your power-bank.
- 3 Do not drop, wet, misuse, or attempt to disassemble the power-bank.

- 4 Keep the power-bank away from any heat source.

- 5 Ensure your power-bank is fully charged at least once every few months.
- 6 This power-bank is compatible with 5V-input digital products.

TROUBLE SHOOTING

- 1 Power-bank not working:
 - Is the relevant charging cable properly connected to your device?
 - Is the power-bank turned on?
 - Is there sufficient battery life available?
 - Is the device you are charging rated at 5V input?
- 2 Why is the power-bank charging, stopping, and restarting:
 - If the power-banks charging current is excessive, the units overload protection function will be activated. To reset the power-bank, simply fully charge the unit.