

iGear™

.com.au



iGear Item Code:IG1925

Search Code: iGear-IG1925

iGear.com.au Pty Ltd

Power On/Off

1. Power On:
 - Long press power button for 3 seconds to power on, voice prompt will indicate power is on.
 - The earbuds automatically connect to each other once power is on.
1. Power Off:
 - Turn off the power by placing the earbuds into the charging case, or
 - Long press the power button for 3 seconds, voice prompt will indicate power is off.
 - When power is on, if not successfully paired to your device, the earbuds will automatically power off after 3 minutes.

Pairing the earbuds with your device

1. Keep the earbuds within a 10metre range of your device.
2. Cancel other previously paired Bluetooth electronics from your device or turn off your Bluetooth function.
3. Power on the earbuds.
4. Activate the Bluetooth function on your phone device, select the pairing name "iGear-IG1925" from the list of Bluetooth devices found, pair your earbuds with your phone.
5. After successfully pairing, both LED indicators on your earbuds will turn off.

How to troubleshoot if pairing your earbuds was unsuccessful.

- Power on both earbuds. Both earbud indicator lights will flash red & blue

- Double press on/off button on either one of your earbuds, earbuds will re-pair to each other. Once successfully paired, one of the LED indicators on the earbuds will turn off. You can now re-pair the earbuds to your device.
- If re-pairing your earbuds is unsuccessful repeat the above steps.

Unpairing the earbuds from your device.

- Place the earbuds back into the charging case, the earbuds will automatically disconnect from your device, or
- Unpair the earbuds from your device, or
- Power off the earbuds, or
- Turn off your device's Bluetooth function

Take/Reject a call.

- Simply press the functionality button to take an incoming call.
- Long press the functionality button for 2 seconds to reject the incoming call.
- Simply press the functionality button to hang up during a call.

Music

- Short press the functionality button to pause/start your music.
- Long press the right functionality button for 2 seconds to use voice function
- Press the left functionality button three times to skip forward song.
- Press the right functionality button three times to skip back song.
- Double press the left functionality button to increase volume.
- Double press the left functionality button to reduce volume.

Charging the earbuds.

- Place your earbuds in the charging case.
- When the LED indicator on your earbuds is red your earbuds are charging.
- When fully charged the red LED indicator on your earbuds will turn off.
- If battery is low a warning tone will emit from your earbuds every 5 seconds.

Charging the earbuds case

- When the battery in the charging case is low the LED indicator will show battery level.
- Connect your charging case to a power source via USB micro cable supplied.
- Whilst charging, the LED indicator will flicker.

Additional information.

Make sure the earbuds are paired before use and the Bluetooth function is activated on your phone.
Make sure the earbuds are charged before use.

Safety use of the lithium battery

The lithium batteries inside these products are not removable, do not attempt to remove these batteries.

Charging case power input: DC 5V/500mAh
Earbuds power input DC 5V/50mAh
Charging environment: 10~50°C
Keep the earbuds and the charging case away from extreme temperatures and water.