

IG1858 : IG1859 : IG1860



## Portable Power Bank USER MANUAL

This product is applicable to digital products  
5V input. Please read the whole  
user manual prior to use.

### OPERATING INSTRUCTIONS

- 1 Power Switch : This button is used to turn on/off the power bank and to check the battery status.
- 2 Battery Level Indicator button is used to check the battery level. All four lights on indicates a full battery.
- 3 Input : Use Micro USB cable to charge the powerbank.
- 4 Output : This power bank is compatible with all digital products with 5V input.



Instruction : If the LED light is flashing,  
press the power button twice within  
three seconds to turn on/off.

### HOW TO CHARGE THE POWER BANK

- 1 Connect the power bank to a computer, laptop or power adaptor with a Micro USB cable.
- 2 The battery level Indicator will be flashing when the power bank is charging.
- 3 When fully charged, the battery level indicator light is on, not flashing.



Notice : Short circuit protection can be  
caused by improper operation, which  
will then shut down the power bank.  
To reactivate, recharge and reset  
the power bank.

### BATTERY INDICATOR

| Battery Indicator | Battery Level |
|-------------------|---------------|
| One Light         | 0% - 25%      |
| Two Lights        | 25% - 50%     |
| Three Lights      | 50% - 75%     |
| Four Lights       | 75% - 100%    |

### HOW TO USE THE POWER BANK

- 1 Ensure the output of the digital device you are charging is 5V.
- 2 Use a qualified USB cable to connect the power bank by the USB port to your device.
- 3 Switch on the power bank and charging will commence.

This power bank can support digital devices such  
as most smart phones, tablets, PSP, MP3, MP4 etc.

### NOTES

- 1 Ensure power bank is fully charged on first use.
- 2 To avoid damage to the power bank, use a qualified cable to charge your device.
- 3 Prior to first use, ensure your device output is 5V.
- 4 Do not beat, knock, misuse or disassemble the power bank or try to repair it yourself.
- 5 Do not put this power bank near any heat source or in a flammable environment.
- 6 Do not put any other objects in the input/output port of the power bank. It could lead to short circuit and damage.
- 7 Ensure the power bank is fully charged at least once per three months.

### FAQ

- 1 Why is my power bank not working?  
Check the following;
  - Is the USB cable functioning and connected?
  - Is the power bank turned on?
  - Is there enough battery left in the power bank?
  - Is the device compatible to the power bank (5V)?
  - Is the power bank in short-circuit protection?  
Answer yes to any of the above? Recharge and reset to reactivate the power bank.
- 2 The charging stops and starts?  
Because the charging current is excessive and the over current protection function is activated. Reboot the power bank and it will begin charging.
- 3 Why can't my power bank charge this device?  
This power bank is only applicable to digital products with a 5V input.